


Exchange Server Tips

Configure Exchange Server to allow the computer running Data Capture the right to relay email. In exchange 2007 do this by creating a New Receive Connector under the Hub Transport.

Full error code can be found in a file called ***lastsentemailresult.html*** generally located in *C:\Program Files (x86)\Temperature Guard\Data Capture* if you are having issues getting it working.



If you are required to authenticate (normally you are not) then the From Address is linked to the login authentication.